



POP OF COLOUR

MAKE A CHIC STATEMENT WITH COLOUR!

A pop of colour on a piece of accent furniture can add style and character to any room! Rust-Oleum® Painter's Touch+ spray paint helps you create a chic statement out of any ordinary object!

Items

- Rust-Oleum Painter's Touch+ Orange spray paint
- Rust-Oleum Painter's Touch+ Primer spray (recommended)
- Dresser
- Drop cloth
- Lint-free cloth
- Sandpaper

STEPS

- 1. PREPARE:** Always work in a well-ventilated area. Cover the ground and any nearby items with a drop cloth to protect from spray mist. Lightly sand the wooden surface of the dresser to rough it up. Wipe clean with lint-free cloth, removing all dust. Priming is especially recommended for bare wood, use Painter's Touch+ Primer for superior adhesion.
- 2. PAINT:** Shake can for 1 minute after the mixing ball begins to rattle. Hold the can 25-40cm from the surface and spray in a steady back and forth motion, slightly overlapping with each stroke. For best results, while spraying, keep the can the same distance from the surface and keep the can in motion. Apply several light coats a few minutes apart.
- 3. FINISH:** Allow the dresser to fully dry for 24 hours before handling. Add stylish hardware to complete your update!



Visit www.rustoleum.com.nz for more fun project ideas!

RUST-OLEUM®
THIS CHANGES EVERYTHING.