

MODERN SIDEBOARD

ADD YOUR OWN TOUCH OF STYLE TO OLD FURNITURE

Serve in style at your next dinner party when you update your sideboard with a coat of Rust-Oleum[®] Painter's Touch+ Dazzle Red spray paint!

ltems

- Rust-Oleum Painter's Touch+ Dazzle Red spray paint
- Rust-Oleum Painter's Touch+ Primer spray (recommended)
- Drop cloth
- · Lint-free cloth

• Sideboard

STEPS

- PREPARE: Always work in a well-ventilated area. Cover the ground and any nearby items with a drop cloth to protect from spray mist. Make sure surface is clean from dirt and dust. Wipe clean with a damp lint-free cloth and let dry. Priming is especially recommended for bare metal, use Painter's Touch+ Primer for superior adhesion.
- **2. PAINT:** Shake can for 1 minute after the mixing ball begins to rattle. Hold the can 25-40cm from the surface and spray in a steady back and forth motion, slightly overlapping with each stroke. For best results, while spraying, keep the can the same distance from the surface and keep the can in motion. Apply several light coats a few minutes apart.
- 3. FINISH: Allow the sideboard to fully dry for 24 hours before handling.



Visit www.rustoleum.com.nz for more fun project ideas!

